

Table Of Contents

General Information and Maintenance Advice	2
Assembly Instructions	3-6
Part List	7


General Information and Maintenance Advice

Be sure to read the entire manual before you assemble or operate your Cable Machine. Please note the following precautions:

- 1. Keep children and pets away from the Cable Machine
- 2. To be used by one person at a time
- 3. Do not use the equipment near water or outdoors
- 4. Position on a level surface
- 5. Keep hands away from moving parts
- 6. Always wear appropriate workout clothing when exercising. Do not wear clothing that could become caught in the equipment.
- 7. Use the equipment only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- 8. Before using the equipment, always do stretching exercises to properly warm up.
- Never operate the equipment if the equipment is not functioning properly.

Warranty Terms

- The Frame is under warranty for 10 years against manufacturing defects
- Integral bearings, guide rods, pulleys, weight plates, cables and grips are under warranty for 1 year against manufacturing defects
- Upholstery is under warranty for 90 days against manufacturing defects
- Warranty does not extend to wear and tear through normal use, or rust






STEP 2

STEP1:Thread The Two Guide Rods (12#) Through 4# At The Same Time.

STEP2:Thread The Two Guide Rods (12#) To The Tube (1# And 2#) At The Same Time.




INFORMATION


We recommend having a second person assist with lifting heavy items during assembly.

STEP 3



NOTE: Adjust 1# and 2# to parallel position and then tighten all the bolt.





PARTS LIST

PART#	DESCRIPTION	QTY
1	Left Main Frame	1
2	Right Main Frame	1
3	Linking Frame	1
4	Sliding Frame	1
5	Base Frame	1
6	Footrest Plate	1
7	Back Pad Support Frame	1
8	Left Position Tube	1
9	Right Position Tube	1
10	Adjusting Plate 1	1
11	Adjusting Plate 2	1
12	Guide Rod	2
13	Long Barbell Rod	4
14	Back Pad	1
15	Head Pad	1
16	Seat Pad	1
17	Position Plate	1
18	Fixing Bushing	2
19	Short Barbell Rod	4
20	Pull Pin	1
21	*	*
22	*	*
23	Shaft 3	1
24	Shaft 4	1
25	Plate	2
26	Strengthening Plate 1	2
27	Strengthening Plate 2	4
28	Strengthening Plate 3	2
29	Ring	2
30	Big Washer	4
31	Bushing 1	8
32	Bushing 2	2
33	Handle Cap	6
34	Clip	4
35	Linear Bearing	4
36	Circlips	4
37	D Cap	2
38	Pt50x100 Cap	1
39	Pt40x80 Cap 1	2
40	D48 End Cap	4
41	D25 Cap	8
42	Bumper 1	2
43	D48 Ring	4
44	Rubber Plate 1	1
	•	

PART #	DESCRIPTION	QTY
45	Rubber Plate 2	4
46	Rubber Plate 3	1
47	Rubber Plate 4	1
48	Rubber Plate 5	2
49	Grip 1	5
50	Grip 2	1
51	Linking Tube 1	1
52	Linking Tube 2	1
53	Pt40x80 Cap 2	1
54	Pt65x115 Cap	1
55	Rubber Round Cap	4
56	*	*
57	Function Board	1
A10-4	Allen Bolt M10x20	2
A10-5	Allen Bolt M10x25	2
CH5-4	Countersunk Head Screw M5X10	6
S5-1	Socket Set Screw M5x4	12
S8-3	Socket Set Screw M8x8	2
SC8-6	Socket Cap Screw M8x30	6
SC10-3	Socket Cap Screw M10x15	2
SC10-4	Socket Cap Screw M10x20	6
SC10-5	Socket Cap Screw M10x25	10
SC10-7	Socket Cap Screw M10x35	8
SC10-13	Socket Cap Screw M10x65	5
SC10-16	Socket Cap Screw M10x80	12
SC10-17	Socket Cap Screw M10x85	4
SC10-22	Socket Cap Screw M10x110	3
SC12-15	Socket Cap Screw M12x75	4
W8	Washer Ф8	6
W10	Washer Φ10	76
W12	Washer Φ12	8
N10	Nut M10	30
N12	Nut M12	4